



Motion Pro, Inc.
867 American Street
San Carlos, CA 94070
Tel 650.594.9600 Fax 650.594.9610
www.motionpro.com

INSTRUCTIONS

ARMOR RIM STRIP TAPE P/N 11-0061 & 11-0062



Step 1

CLEAN YOUR RIM (do not use WD-40 or other like products that leave an oily residue as this will prevent the tape from sticking correctly)

Step 2

Peel paper backing off the tape just past the hole on the short end.

Step 3

Align the hole in the tape with the Schrader valve hole on the rim, and press down the exposed adhesive section of the tape.

Step 4

Continue by simultaneously pulling off the paper backing and firmly seating the rim tape over the spoke nipples in the center of the rim until the two ends overlap.

Step 5

Cut the hole for the rim lock with a hobby knife once the tape has been fully installed.

USE CAUTION WITH THE HOBBY KNIFE TO AVOID INJURING YOURSELF.



Motion Pro, Inc.
867 American Street
San Carlos, CA 94070
Tel 650.594.9600 Fax 650.594.9610
www.motionpro.com

INSTRUCTIONS

ARMOR RIM STRIP TAPE P/N 11-0061 & 11-0062



Step 1

CLEAN YOUR RIM (do not use WD-40 or other like products that leave an oily residue as this will prevent the tape from sticking correctly)

Step 2

Peel paper backing off the tape just past the hole on the short end.

Step 3

Align the hole in the tape with the Schrader valve hole on the rim, and press down the exposed adhesive section of the tape.

Step 4

Continue by simultaneously pulling off the paper backing and firmly seating the rim tape over the spoke nipples in the center of the rim until the two ends overlap.

Step 5

Cut the hole for the rim lock with a hobby knife once the tape has been fully installed.

USE CAUTION WITH THE HOBBY KNIFE TO AVOID INJURING YOURSELF.

