



PAD INSTALLATION

Remove adhesive backing and install pad over LiteLoc™ bolt with adhesive facing rim lock. The foam pad works as a dampening device to inhibit spokes from loosening and to keep LiteLoc™ properly aligned in rim hole.



Motion Pro, Inc. • 867 American Street, San Carlos, CA 94070 • MotionPro.com