

INSTRUCTIONS

MOTION PRO Dowel Pin Puller Set P/N 08-0603



- Step 1: Select the correct size collet for the dowel pin you are going to remove
- Step 2: Tighten the 6 mm bolt on the collet to lock it firmly onto the dowel pin
- Step 3: Select the slide hammer, puller rod, or open end wrench for pulling the dowel pin

Note: For frozen pins use the slide hammer



Maximum torque for 6 mm bolt is 7 lb/ft









Additional Dowel Puller Sizes Are Available:



21 mm 08-0707

19 mm 08-0708

17 mm 08-0709

13.8 mm 08-0710 12.5 mm 08-0711